Submit 2 Conice To Americanista Distri	ict a	tate of New Mexic	00		Form C-1	03
Submit 3 Copies To Appropriate Distri Office	· ·				Revised March 25, 1	
District I	•••	linerals and Natural	Resources	WELL API NO.		
1625 N. French Dr., Hobbs, NM 88246 District II		NSERVATION D	IVISION	30-025-003		
811 South First, Artesia, NM 88210		2040 South Pached		5. Indicate Type	of Lease	
<u>District III</u> 1000 Rio Brazos Rd., Aztec, NM 8741	10			STATE [X FEE 🗆	
District IV	ು	Santa Fe, NM 8750	03	6. State Oil &	Gas Lease No.	
2040 South Pacheco, Santa Fe, NM 87		OD THE CALL THE CALL		022351	TT14 A 4.3.7	
SUNDRY N (DO NOT USE THIS FORM FOR PR DIFFERENT RESERVOIR. USE "A PROPOSALS.) 1. Type of Well:	NOTICES AND REPORT OF STATE OF SALS TO DRILL OF SPECIAL OF SERVICE	R TO DEEPEN OR PLUG	BACK TO A SUCH	TexMack	or Unit Agreement N 6 State	ame
Oil Well Gas We	ll 👿 Other					
2. Name of Operator				8. Well No.		
Texaco Explorat	ion & Produc	tion, Inc.			1	
3. Address of Operator	Midland m-	wag 7070 f			or Wildcat Anders	SOI
P. O. Box 3109,	Midiand, Te	xas 7970 \$		Ranch West	(Penn)	
4. Well Location	•					
Section 6		nship 16S Rang n (Show whether DR,		NMPM Lea	County	
				, , , , , , , , , , , , , , , , , , ,		
NOTICE O	ck Appropriate Bo F INTENTION T			, Report or Other BSEQUENT RE	PORT OF:	
PERFORM REMEDIAL WORK	K □ □ PLUG AND AI	BANDON X	REMEDIAL WO	RK	ALTERING CASIN	G[
				RK RILLING OPNS.[]	ALTERING CASING PLUG AND] _ _
TEMPORARILY ABANDON	CHANGE PLA	ANS	COMMENCE D	RILLING OPNS.		G[]
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING		ANS		RILLING OPNS.	PLUG AND	G[
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	CHANGE PLA MULTIPLE COMPLETION	ANS	COMMENCE DE CASING TEST A CEMENT JOB OTHER:	RILLING OPNS.	PLUG AND ABANDONMENT	
TEMPORARILY ABANDON PULL OR ALTER CASING	CHANGE PLA MULTIPLE COMPLETION completed operations	ANS (Clearly state all pe	COMMENCE DE CASING TEST A CEMENT JOB OTHER:	RILLING OPNS. AND and give pertinent da	PLUG AND ABANDONMENT tes, including estimate	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 4200'-40 clug 2900'-27 clug 1300'-11 c @ 700', Sqz	ANS S. (Clearly state all per loss). For Multiple Company Spot 4. Brine 25# company (Csg Pat loss). (Yates-Foo' (Yates-Foo' (T-Salt)). 125 Sx 700'	COMMENCE DE CASING TEST A CEMENT JOB OTHER: ertinent details, a completions: Attained by the completion of the completio	AND and give pertinent date wellbore diagram g 11,700'-11 f for vo C Tag 3 3/8" shoe)	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To	ed dion
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 2900'-40 clug 2900'-27 clug 1300'-11	ANS S. (Clearly state all per loss). For Multiple Company Spot 4. Brine 25# company (Csg Pat loss). (Yates-Foo' (Yates-Foo' (T-Salt)). 125 Sx 700'	COMMENCE DE CASING TEST A CEMENT JOB OTHER: ertinent details, a completions: Attained by the completions of the completion of the comment of	AND and give pertinent datach wellbore diagram and 11,700'-11 Appr 10 Tag 3 3/8" shoe) er. SISSION MUST BE NOR TO THE BEGIOPERATIONS FOR	PLUG AND ABANDONMENT Ites, including estimate of proposed complet ,500! WOC To SX Plug S200 WOC Tag NOTIFIED 24 NNING OF	ed dion
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE I @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 5100'-49 clug 2900'-27 clug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS S. (Clearly state all persons) Penn) Spot 4 Brine 25# cool (Csg Pat 200' (9 5/8" 200' (Yates-Foo' (T-Salt)) 125 Sx 700' (Install dry here)	CASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of the properties of the properties of the properties of the community of the properties of the properties of the community of the communi	AND and give pertinent datach wellbore diagram and 11,700'-11 Apar Value Tag 3 3/8" shoe A 10 THE BEGIOPERATIONS FOR	PLUG AND ABANDONMENT Ites, including estimate of proposed complet ,500! WOC To SX Plug S200 WOC Tag NOTIFIED 24 NNING OF	ed dion
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes 8. 10 Sx Surf,	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 4200'-40 clug 2900'-27 clug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS S. (Clearly state all persons) Penn) Spot 4 Brine 25# 9 00' (Csg Pate) 00' (7-Salt) 2 125 Sx 700' Constall dry hand complete to the bear of the state of th	COMMENCE DECASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of my knowless of my knowl	AND and give pertinent da ach wellbore diagram and 11,700'-11 AND Tag 3/8" shoe) er. AISSION MUST BE NOR TO THE BEGIOPERATIONS FOR ROVED.	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To SX Plug WOC Tag WOC Tag NOTIFIED 24 NNING OF RTHE C-103	[ag ag
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes 8. 10 Sx Surf,	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 4200'-40 clug 2900'-27 clug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS S. (Clearly state all persons) Penn) Spot 4 Brine 25# 9 00' (Csg Pate) 00' (7-Salt) 2 125 Sx 700' Constall dry hand complete to the bear of the state of th	COMMENCE DECASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of my knowless of my knowl	AND and give pertinent da ach wellbore diagram and 11,700'-11 AND Tag 3/8" shoe) er. AISSION MUST BE NOR TO THE BEGIOPERATIONS FOR ROVED.	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To SX Plug WOC Tag NOTIFIED 24 NNING OF R THE C-103	ed dion ag
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hol 3. Spot 40 Sx p 4. Spot 40 Sx p 5. Spot 40 Sx p 6. Spot 40 Sx p 7. Perf 6 holes 8. 10 Sx Surf,	CHANGE PLA MULTIPLE COMPLETION completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# clug 5100'-49 clug 4200'-40 clug 2900'-27 clug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS S. (Clearly state all persons) Penn) Spot 4 Brine 25# 9 00' (Csg Pate) 00' (7-Salt) 2 125 Sx 700' Constall dry hand complete to the bear of the state of th	COMMENCE DECASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of my knowless of my knowl	AND and give pertinent da ach wellbore diagram and 11,700'-11 AND Tag 3/8" shoe) er. AISSION MUST BE NOR TO THE BEGIOPERATIONS FOR ROVED.	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To SX Plug WOC Tag NOTIFIED 24 NNING OF R THE C-103	ed dion ag
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pt 4. Spot 40 Sx pt 5. Spot 40 Sx pt 6. Spot 40 Sx pt 7. Perf 6 holes 8. 10 Sx Surf, I hereby certify that the information of the series of th	MULTIPLE COMPLETION Completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# colug 5100'-49 colug 4200'-40 colug 2900'-27 colug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS Constall dry ANS Constall dry Consta	COMMENCE DECASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of my knowless of my knowl	AND and give pertinent da ach wellbore diagram and 11,700'-11 AND Tag 3/8" shoe) er. AISSION MUST BE NOR TO THE BEGIOPERATIONS FOR ROVED.	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To SERVICE WOC Tag WOC Tag NOTIFIED 24 NNING OF RTHE C-103 DATE 4/24/6 ephone No.666-44	ed dion ag
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or confistering any proposed or recompilation. 1. Set 7" CIBP 2. Displace hold 3. Spot 40 Sx pp 4. Spot 40 Sx pp 5. Spot 40 Sx pp 6. Spot 40 Sx pp 7. Perf 6 holes 8. 10 Sx Surf, I hereby certify that the information of the series of th	MULTIPLE COMPLETION Completed operations work). SEE RULE 1 @ 11,700', (le w/MLF 9.5# colug 5100'-49 colug 4200'-40 colug 2900'-27 colug 1300'-11 s @ 700', Sqz 10'-Surf. I	ANS S. (Clearly state all persons) Penn) Spot 4 Brine 25# 9 00' (Csg Pate) 00' (7-Salt) 2 125 Sx 700' Constall dry hand complete to the bear of the state of th	COMMENCE DECASING TEST ACEMENT JOB OTHER: ertinent details, a completions: Attained the properties of my knowless of my knowl	AND and give pertinent da ach wellbore diagram and 11,700'-11 AND Tag 3/8" shoe) er. AISSION MUST BE NOR TO THE BEGIOPERATIONS FOR ROVED.	PLUG AND ABANDONMENT Ites, including estimate of proposed complet 7500! WOC To SX Plug WOC Tag NOTIFIED 24 NNING OF R THE C-103	ed dion ag