

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-7177</b>
7. Unit Agreement Name <b>Robinson Unit</b>
8. Farm or Lease Name <b>Robinson Unit Tr. 5-31</b>
9. Well No. <b>15</b>
10. Field and Pool, or Wildcat <b>Malj. Grayb. S.A.</b>
12. County <b>Lea</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator <b>Aztec Oil &amp; Gas Co.</b>
3. Address of Operator <b>P. O. Box 837, Hobbs, New Mexico 88240</b>
4. Location of Well UNIT LETTER <b>0</b> <b>990'</b> FEET FROM THE <b>south</b> LINE AND <b>2310'</b> FEET FROM THE <b>east</b> LINE, SECTION <b>31</b> TOWNSHIP <b>16</b> RANGE <b>32</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>4080 GR</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 5½" BP @ 3750'.
- Dump 4 Sx. cement on top.
- Spot 35 Sx. plug @ 980'.
- Spot 35 Sx. Plug @ 600', cut off 5½".
- Spot 50 Sx. plug @ 250'.
- Spot 10 Sx. plug @ surface.
- Install dry-hole marker and clean location.  
Hole loaded w/mud and displaced w/mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Gay Baker</i></u>	TITLE <u>Agent</u>	DATE <u>5/2/75</u>
APPROVED BY <u><i>John W. Ramsey</i></u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		