

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Index: Bureau No. 10-1-100
Indices August 31, 1988

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER <u>Injection</u>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR <u>Conoco Inc.</u>	8. FARM OR LEASE NAME <u>William Mitchell B</u>
3. ADDRESS OF OPERATOR <u>P.O. Box 460, Hobbs, NM 88240</u>	9. WELL NO. <u>#8</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) <u>At surface</u> <u>1980' FSL & 1980' FEL</u>	10. FIELD AND POOL, OR WILDCAT <u>Maljamar G-SA</u>
14. PERMIT NO. <u>30-025-00593</u>	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>Sec. 17, T17S, R32E</u>
15. ELEVATIONS (Show whether DF, RT, CR, etc.) <u>4018' KB</u>	12. COUNTY OR PARISH <u>Lea</u>
	13. STATE <u>NM</u>

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.*

1. MIRU and kill well if necessary w/10 ppg mud. ND wellhead. NU BOP. POOH w/2-3/8" production tbg and 5-1/2" Loc-set RBP @ 3658'.
2. Abandon perms from 3758-3838'. RIH w/CIBP on tbg. Set CIBP @ 3683'. Spot 25 sx of Class "C" cement on CIBP from 3683-3447'. PU and circulate hole w/10 ppg mud. POOH.
3. Cement production csg. Spot 43 sx Class "C" Neat cement from 279-0'.
4. Erect a permanent steel P&A marker over the wellbore.

18. I hereby certify that the foregoing is true and correct

SIGNED W.W. Baker TITLE Administrative Supervisor DATE June 20, 1989

(This space for Federal or State office use)

APPROVED BY Shamir Shaw FOR: Chief of Bureau DATE 6/27/89

CONDITIONS OF APPROVAL, IF ANY

Subject to
Like Approval
by State

*See Instructions on Reverse Side

Mitchell 'B' No 8

EC 17, T-17S, R-32E

EL. LF-41007.

KB-4018.

Cellar Filled
w/CMT and/or SAND
To surface contour

Proposed Well Bore Diagram

ABANDONMENT MARKER
"MITCHELL 'B' No. 8"
T-17-T17S-R32E

3' or BTM of cell
whichever is
greater

8 5/8", 24# @ 229'
w/100 SX (CIRC)

Fill w/43 SX CLASS 'C'
@ 279' - 0

TS - 873'
BS - 1930'

10 PPG
mud

25 SX CLASS 'C' w/2% C-CL₂
(3683 - 3447')

- SET CIBP @ 3683'

3758-68' > 4 JSPF
3784-90' >
3812-22' > 2 JSPF
3828-38' >

BTM FILL Tagged @ 4015'
9/6/68

5 1/2", 14# @ 4200'
w/775 SX CMT
(CSG reciprocated)
(CMTd. To surface)

5-22-87