

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.

LC-029509A

6. If Indian, Allotment or Tribe Name

7. If Unit or CA, Agreement Designation

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Conoco Inc.

3. Address and Telephone No.

10 Desta Dr. Midland, TX 79705

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FNL & 660 FWL

Letter E, Sect. 22, T17S, R32E

8. Well Name and No.

Baish A No. 2

9. API Well No.

30-025-00623

10. Field and Pool, or Exploratory Area

Maljamar (G-SA)

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(es) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1-15-91 CO from 2320 to 2335. Tst csg, pmp 14 BBLs - pressure went to 1000#, pull bit out of hole, SD - talk to BLM - OK to run ret + pmp cmt at 1000#.

1-17-91 Run ret to 2200 + set, pmp 175 SXS cmt, string out of ret, pmp 25 SXS on top of ret, pull tbg to 1025, spot 35 SXS cmt from 1025 to 800, pull tbg out of hole, wait on cmt.

1-18-91 Tag cmt at 800, lay all tbg down, perf well at 225, pmp 60 BBLs mud, could not circ, pmp 265 SXS cmt, pmp 230 SXS cmt, disp to 250.

1-19-91 Run tbg in hole to 223, circ 50 SXS cmt from 225 to surf, pull tbg out, cut off wellhead, fill csg w/cmt, put in marker.

Plug & abandon 1-19-91

14. I hereby certify that the foregoing is true and correct

Signed

Christine Neff

for

Title Analyst - Oil Production

Date 4-9-91

(This space for Federal or State office use)

Approved by

Christine Neff

Title

Date

6-6-91

Conditions of approval, if any:

RECEIVED

JUN 10 1991

OCS
POSTS OFFICE