

- E. Cut off dead-man anchors below ground level and remove markers.
Fill in cellar and workover pit.
 - F. Remove all equipment, concrete bases, and pipe not in use.
 - G. Clean and restore location to its natural state. Reseed
according to BLM requirements.
10. Send a copy of the well service report and final P&A schematic to
the Division office so the proper forms can be filed.

Approved:

Tom C. Admuddell for STD
Production Specialist

8-21-90
Date

Jay Vahler
Engineer

8-28-90
Date

Gai Juman
Supervising Production Engineer

9/7/90
Date

for Joe L. Conder
Division Engineering Manager

9/24/90
Date

Sam Patton
Production Superintendent

9/27/90
Date