

- E. Cut off dead-man anchors below ground level and remove markers.  
Fill in cellar and workover pit.
  - F. Remove all equipment, concrete bases, and pipe not in use.
  - G. Clean and restore location to its natural state. Reseed  
according to BLM requirements.
10. Send a copy of the well service report and final P&A schematic to  
the Division office so the proper forms can be filed.

Approved:

Tom C. Luddell for STB  
Production Specialist

B-21-90  
Date

\_\_\_\_\_  
Engineer

\_\_\_\_\_  
Date

\_\_\_\_\_  
Supervising Production Engineer

\_\_\_\_\_  
Date

\_\_\_\_\_  
Division Engineering Manager

\_\_\_\_\_  
Date

\_\_\_\_\_  
Production Superintendent

\_\_\_\_\_  
Date