

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ <u>Injection Well</u>	7. UNIT AGREEMENT NAME <u>MCA Unit Unit</u>
2. NAME OF OPERATOR <u>Conoco Inc.</u>	8. FARM OR LEASE NAME <u>MCA Unit Unit</u>
3. ADDRESS OF OPERATOR <u>P.O. Box 460 - Hobbs, New Mexico 88240</u>	9. WELL NO. <u>200</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>660' FSL & 660' FFL - Unit Letter P</u>	10. FIELD AND POOL, OR WILDCAT <u>Maljamar G-5A</u>
14. PERMIT NO. <u>30-025-00688</u>	15. ELEVATIONS (Show whether DF, RT, GR, etc.)
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>25-17S-32E</u>	12. COUNTY OR PARISH <u>Lea</u>
	13. STATE <u>NM</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1) MIRU. POOH w/ tag & tension pkl.

2) Spot balance cement plug from 4317'-3730'. G1H w/open ended workstring, Spot 100 sxs class "C" cement w/ 2% CaCl₂ from 4317'-3730'. Displace w/ 21.5 bbls water. POOH. Tag cement plug. Circ hole w/ 100 bbls 9.5 ppg mud & POOH.

3) Spot 35 sxs class "C" w/ 2% CaCl₂ cement plug from 260' to surface.

4) Cut off csg at base of collar or 3' below ground level.

5) Fill csg from cement plug back to surface w/sand, cement or gravel.

6) Weld 1/4" steel plate over wellbore.

7) Install P & A marker

8) Clean location.

For further information contact Barry Schneider at 397-5800

18. I hereby certify that the foregoing is true and correct

SIGNED

D F FINNEY

TITLE Administrative Supervisor

DATE

9/19/88

This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

9-22-88

Subject to
Like Approval
by State

*See instructions on Reverse Side

Under the Department 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

BLM-Carlbad(6) OXU(1) FPCO(1) L.L.

SEP 20 1988
RECEIVED

MCA Unit 200

660' FS & E

Elev 4000'

35 sx plug @ 260'

perfs: 750'-794' sgz'd w/ 200 sxs

1048'-1050' sgz'd w/ 150 sxs (circ. cnt to surface)

TOC @ 2900' (Base of salt)

100 sxs plug @ 3730'

PBTD 4317

TD 4435'

Made By B.C.S.

Checked By

Date 2-2-82

Page of

Conoco Inc.
Calculation Sheet

Title Proposec Wellbore

Job No.

Field

State

RECEIVED

SEP 26 1988

OOD
MOBBS OFFICE