

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other Instructions on
Reverse Side)

Form approved.
Budget Bureau No. 42 R1424.
5. LEASE DESIGNATION AND SERIAL NO.

LC-057210

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

BAISH B Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

MALJAMAR ABO

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

28-17-32 NMPM

12. COUNTY OR PARISH 13. STATE

LEA N.M.

1. NAME OF OPERATOR

2. ADDRESS OF OPERATOR

Production Company

3. ADDRESS OF OPERATOR

Box 62, Hobbs, N. M. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See page 17 below.)

2120' FSL x 519' FEL Sec. 28 (Unit I, NE 1/4 SE 1/4)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3992' R D B

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRAC TURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRAC TURE TREATMENT

SHOOTING OR ACIDIZING

(Other) S

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

Evaluations of well indicate no further use
anticipated. Propose to Plug & Abandon as follows:

Spot 50 sz cement plug from PBD-9030 - 8200 to cover
perforated interval 8886 - 8840.

Shot and pull 4 1/2" Casing from free point. (Est 5500 - 6000')

Spot 35 sz cement plug in & out of 4 1/2" stub. (If pulled from
below 5440' (T-Glor) spot 35 sz @ T GLORIETTA.

Spot 35 sz in & out of 8 7/8" Casing shoe @ 4576'.

Spot 10 sz @ surface & erect P: A marker.

Make final cleanup and level location.

all intervals to be filled w/ heavy mud.

TD - 9630' 13 7/8" CSA 360. Circ
PBD-9030' 8 7/8" " 4576. TCMT 40'
4 1/2" " 9180' " 8040'

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

AREA ENGINEER

DATE

7-9-73

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF

APPROVAL, IF ANY:

Place additional 35 sack cement plug in
8 7/8" casing interval 9000-8840 feet.

45- USGS-H
1- DIV
1- SOSP
1- KRY

*See Instructions on Reverse Side

APPROVED
JUL 10 1973
ARTHUR L. BROWN
DISTRICT ENGINEER