

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B-9380</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name -
2. Name of Operator <b>TEXACO Inc.</b>		8. Farm or Lease Name <b>New Mexico 'AQ' St. NCT-</b>
3. Address of Operator <b>P.O. Box 728, Hobbs, New Mexico 88240</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>F</b> , <b>2271</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>3</b> TOWNSHIP <b>15-S</b> RANGE <b>33-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Saunders Permo-Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.)		12. County <b>Lea</b>

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JQB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**TEXACO Inc. has completed the following work on subject well.**

1. Recovered 5,061' 5-1/2" casing.
2. Set CIBP at 9,700' w/3 sx cement plug on top.
3. Set 25 sx cement plug at 5,061'.
4. Set 25 sx cement plug at 4,290'.
5. Set 10 sx cement plug at surface.
6. Install 4" dry hole marker extending 4' above ground level. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Nathan E. Clegg</i></u>	TITLE <b>Assistant District Superintendent</b>	DATE <b>December 3, 1971</b>
APPROVED BY <u><i>Nathan E. Clegg</i></u>	TITLE <b>OIL &amp; GAS INSPECTOR</b>	DATE <b>MAR 28 1972</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

DEC 2 1971

OIL CONSERVATION COMM.  
HOUSTON, TEXAS