

JIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-2148	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Pennzoil Company		Western State
3. Address of Operator		9. Well No.
P.O. Drawer 1828, Midland, TX 79702-1828		11
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>810</u> FEET FROM		Maljamar (G-SA)
THE <u>West</u> LINE, SECTION <u>17</u> TOWNSHIP <u>17-S</u> RANGE <u>33-E</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4215 RT		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

ESTIMATED STARTING DATE - NOV. 1985

- Clean out to 4390'.
- Perforate 4170-88' and 4240-45'.
- Spot scale converter and wait 24 hours.
- Acidize old & new perfs with 6000 gallons 15% NE FE HCL acid with block.
- Swab back the load.
- Pump scale preventative and SI overnight.
- Place well back on pump.

Old Perfs: 4208-20, 4268-73, 4282-87, 4305-13, 4330-39, 4351-60, 4364-80.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Petroleum Engineer DATE 10/17/85

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT 1 SUPERVISOR

OCT 31 1985

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: