

RECOMPLETE IN CISCO

Kemnitz State SA Well No. 1

1. MISU PU.
2. Install BOP's.
3. POOH with 2 3/8" tubing.
4. RU wireline company.
5. Perf Cisco with 2 SPF at ~~11,255'-59', 261'-263', 269'-271', 286'-296'~~.
11,254'-58', 62'-72', 85'-11,300'.
6. RD wireline company.
7. RIH with packer on 2 3/8" tubing. Set packer at ±11,200'.
8. ND BOP's. PU wellhead.
9. Acidize per service company recommendation.
10. Swab well in.
11. RD pulling unit.

MDV3/90/dah