

PROCEDURE - Continued
STATE LWA "E" WELL NO. 1
Kemnitz (Cisco) Field
Lea County, New Mexico

Page 2

9. Pull out lay down tubing.
10. Spot plug #6 from 30' to surface (20 sx).
11. Cut off well heads. Weld on 1/2" steel plate.
12. Install dry hole marker, 4" pipe 5' above ground w/legal description welded on pipe.

MIDLAND DISTRICT DRILLING DEPARTMENT
11-4-75 JRH:JLW:1b