

Jan. 9, 1958 Thursday.
Dan Mitter.

Alvon Drdg. Co. San Angelo.
3-16-35

TD 310'

P&A program for Alvon Drdg. Co. well.

1. Remove $\frac{1}{2}$ gallon can from hole.
2. Fill hole with mud laden fluid.
3. Place 30 foot cement plug at surface (i.e. from 30ft. to surface, properly marked).
4. Set marker to side of hole in cement. Clean location.

Note:

Mr. E. L. Minton, Lea County Engineer and I are of the opinion that the above is a minimum requirement. The hole, if not cemented at surface would pose a real hazard.

$$\begin{array}{r}
 82,620,005 \\
 7,500,000 \\
 \hline
 75,120,005
 \end{array}$$

$$\begin{array}{r}
 949 \\
 37 \\
 256 \\
 \hline
 1252
 \end{array}$$

$$\begin{array}{r}
 .9 \\
 \hline
 949 \overline{) 855.0} \\
 841 \\
 \hline
 14
 \end{array}$$

$$\begin{array}{r}
 7,500,000 \\
 12 \\
 \hline
 15000000 \\
 7500000 \\
 \hline
 90,
 \end{array}$$