

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION
 Orig&2cc: OCC, Hobbs, N.M. 11 50 11 '67
 cc: Regional Office
 cc: Partner
 cc: file

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Edison "C" WN
9. Well No. 2
10. Field and Pool, or Wildcat Shoe Bar Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Plug and Abandon
2. Name of Operator Sinclair Oil & Gas Company
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER E, 1980 FEET FROM THE North LINE AND 990 FEET FROM THE West LINE, SECTION 26 TOWNSHIP 16S RANGE 35E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5-2-67 Pulled tubing and spotted 50 sacks cement plug @ 9542'. Filled hole w/heavy mud to between all plugs. Cut and pulled 4572' of 5-1/2"OD casing. Spot 25 sacks cement
 5-8-67 plug in top of 5-1/2"OD casing stub @ 4572'. Spot 10 sacks cement plug @ surface and set regulation marker, clean and levelled location. Plugged and Abandoned off:
 5-8-67

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Superintendent DATE 5-10-67

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: