## MISCELLANEOUSERVATION COMMISSION

S utitepri Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, ber cified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications comider additable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed add work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature	of Notice by	y Checking	r Belon
-----------------	--------------	------------	---------

· · · · · · · · · · · · · · · · · · ·		NOTICE OF INTENTION TEMPORARILY ABANDO			Notice of to Drill I	Intentio Deeper	)N	
NOTICE OF INTENTION TO PLUG WELL		Notice of Intention to Plug Back	, 		Notice of to Set Lin			
Notice of Intention to Squeeze	x	Notice of Intention to Acidize		x	Notice of to Shoot		×	
NOTICE OF INTENTION TO GUN PERFORATE	x	Notice of Intention (Other)			Notice of (Other)	Intentic	<b>X</b>	
OIL CONSERVATION COMM SANTA FE, NEW MEXICO	ISSION		, New M Place)	exico		*****	July 5,	1963
Gentlemen:								
Following is a Notice of Inte								
(Compan	y or Operator	H. Crockett	Lessa		Well No		in	D (Dait)
NW 1/4 NE 1/4 of St (40-acre Subdivision)	<u> </u>	т. 15-S	в <u>36-</u> Е	MMPM	Caudill	Permo	Penn.	(Unit) Beel
-			<b></b>	*****************	<b>, ,,,,,,,,,,,,,,,</b> ,,,,,,,,,,,,,,,,,,,,	*****	****************	·····F00
Lea	Co	unty.				<del>.</del> .	- 	
•		•			•		· · · ·	
	<b>T T T T T</b>							
	FUL	L DETAILS OF PRO	OPOSED	PLAN O	F WORK		· •	
		L DETAILS OF PRO				NS)		•
		L DETAILS OF PRO				NS)		
1. Locate suspected	(FOLLOW	INSTRUCTIONS IN				NS)	ý.	
1. Locate suspected	(FOLLOW	INSTRUCTIONS IN				NS)		
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> </ol>	(FOLLOW casing cement	INSTRUCTIONS IN leak.				<b>NS)</b>		
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and test</li> </ol>	(FOLLOW casing cement st squee	INSTRUCTIONS IN leak. ling. ze job.	THE RUI	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and test</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an	LES AND 1	REGULATIO			
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	,366 an test.	d 10,370	<b>REGULATIO</b>	78.		
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	,366 an test.	d 10,370	REGULATIO	78.		
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	,366 an test.	d 10,370	REGULATIO	78. ng Co.		
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol>	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	,366 an test.	d 10,370	REGULATIO	78. ng Co.		
<ol> <li>Locate suspected</li> <li>Repair by squeezed</li> <li>Drill out and test</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zo	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	,366 an test.	d 10,370	& Refinin	78.	••••••••	
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zc ) gallor	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	Hum	d 10,370	& Refinin	78.	••••••••	
<ol> <li>Locate suspected</li> <li>Repair by squeezed</li> <li>Drill out and test</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zc ) gallor	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	Hum	d 10,370	& Refinin	78.	••••••••	
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zc ) gallor	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an test. Hum By Position	d 10,370 ble Oil Ager Send	& Refinin Company M	78. or Operator	ing well to:	
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zc ) gallor	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an test. Hum By Position	d 10,370 ble Oil Ager Send	& Refinin	78. or Operator	ing well to:	
<ol> <li>Locate suspected</li> <li>Repair by squeeze</li> <li>Drill out and tes</li> <li>Perforate upper H</li> <li>Stimulate with 500</li> </ol> Approved	(FOLLOW casing cement st squee Penn. zc ) gallor	INSTRUCTIONS IN leak. ing. ze job. one 10,363 to 10	THE RUI ,366 an test. Hum By. Position.	d 10,370 d 10,370 ble Oil Ager Send Humble (	& Refinin Company M	78. or Operator in regard	ing well to:	