

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-4287	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name West Lovington Unit
2. Name of Operator TEXACO Inc.	8. Farm or Lease Name West Lovington Unit
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER M, 660 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 33 TOWNSHIP 16-S RANGE 36-E NMPM.	10. Field and Pool, or Wildcat Lovington San Andres West
15. Elevation (Show whether DF, RT, GR, etc.) 3907' (GR)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data.
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTERN CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RIGGED UP.
2. RUN FREE POINT. CUT 5 1/2" CASING ABOVE FREE POINT AND PULL.
3. SPOT 26 SX CEMENT PLUG FROM 50' BELOW TO 50' ABOVE CASING STUB. IF 5 1/2" CASING IS CUT BELOW 8 5/8" CASING SHOW (4708'), THEN SPOT 35 SX (100') ACEMENT PLUG ACROSS CASING SHOE.
4. RUN FREE POINT. CUT 8 5/8" CASING ABOVE FREE POINT AND PULL.
5. SPOT 50 SX CEMENT PLUG FROM 50' BELOW TO 50' ABOVE CASING STUB.
6. SPOT 87 SX CEMENT PLUG FROM 367' - 267'.
7. SPOT 10 SX CEMENT PLUG @ SURFACE.
8. CLEAN LOCATION. INSTALL DRY HOLE MARKER. PLUG AND ABANDON WELL.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE ASST DIST MANAGER DATE 1-6-84

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JAN 9 1984

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
JAN 9 1984
C.C.D.
HOBBS OFFICE