

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
CITY SECTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No.	
B7766	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator: **Texaco producing Inc**

Address of Operator: **P. O. Box 728, Hobbs, NM 88240**

Location of Well: **UNIT LETTER N 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 16S RANGE 36E NMPM.**

10. Field and Pool, or Vldcat: **Lovington San Andres**

15. Elevation (Show whether DF, RT, GR, etc.): **3840' DF**

12. County: **Lea**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REFORM REMEDIAL WORK ☒	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
LL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) MIRU. Pull rods & pump.
- 2) Install BOP. Pull tubing.
- 3) GIH w/4 3/4" bit. Clean out to top of fish @ +4940'.
- 4) GIH w/RBP to +4500'.
- 5) Pressure test csg to 500#. Repair if necessary.
- 6) GIH w/washpipe and shoe. Wash over fish.
- 7) GIH w/overshot and recover fish.
- 8) GIH w/4 3/4" bit. Deepen from 5008' to 5120' (112')
- 9) Run GR-CNL-CAL-CCL 5120-2500'.
- 10) GIH w/pkr to +4450'. Load backside.
- 11) Acidize San Andres OH 4520'-5120' w/10,000 gal gelled 20% NEFE in 3 stages. use +1000# rocksalt between each stage as a block. Mix 2 drums scale inhibitor with the acid (5BPM, 4000#)
- 12) Flow back load.
- 13) GIH w/RBP to +4500'.
- 14) Perf Grayburg 4350-4500 w/4" csg gun w/2 JSPI.
- 15) GIH w/packer to +4300'.
- 16) Acidize GB perms w/5000 gal gelled 15% NEFE AND BALL SEALERS. Mix 1 drum scale inhibitor with the acid (4000#, 5BPM).
- 17) Flow back load.
- 18) Pull RBP.
- 19) Place on production.

The information above is true and complete to the best of my knowledge and belief.

CO. J. W. Browning TITLE District Admin. Supervisor DATE 10/09/86

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT SUPERVISOR TITLE DATE OCT 17 1986

CONDITIONS OF APPROVAL, IF ANY: