

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State ☐	Fee ☒
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER- ☐		7. Unit Agreement Name
2. Name of Operator Lynn Petroleum Consultants, Incorporated		8. Farm or Lease Name McClure "C"
3. Address of Operator P.O. Box 1666, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>990</u> FEET FROM THE <u>East</u> LINE AND <u>330</u> FEET FROM THE <u>North</u> LINE, SECTION <u>14</u> TOWNSHIP <u>15S</u> RANGE <u>37E</u> N.M.P.M.		10. Field and Pool, or Wildcat Denton Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3803		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	COMMENCE DRILLING OPERATIONS ☐
PULL OR ALTER CASING ☐	CASING TEST AND CEMENT JOBS ☐
OTHER ☐	OTHER <u>Recompletion to Wolfcamp</u> ☒
PLUG AND ABANDON ☐	ALTERING CASING ☐
CHANGE PLANS ☐	PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 11,700' with 30' cement on top.
2. Perforate 1 SPF 9566-68 9610-14 9632-38 9652-58 Acidize w/1500 gallons 15% HCL
3. Swab water with show of oil.
4. Perforate 1 SPF 9478-84 9492-95
5. Swab water with show of oil.
6. Perforate 1 SPF 9174-80 9192-96 9200-02 9219-23 9232-35 9259-65 9293-96
7. Swab water & oil.
8. Perforate 1 SPF 9082-84 9091-9106 9118-24 9147-54
9. Swab oil & water, determine communication with lower perforations.
10. Set CIBP at 9210. Squeeze perforations from 9082-9202 with 162 sacks
11. Drill out cement to 9146.
12. Perforate 1 SPF 9082-84 9092-9106 9118-22 (2SPF)
13. Acidize with 2000 gallons 15% HCL and 3000 gallons gelled 20% HCL.
14. Put on pump.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ray W. Ferry TITLE Vice-President DATE October 22, 1984
ORIGINAL SIGNED BY JOHN TERRY
DISTRICT SUPERVISOR
APPROVED BY _____ TITLE _____ DATE OCT 25 1984

CONDITIONS OF APPROVAL, IF ANY: