

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐
2. NAME OF OPERATOR
Continental O. / Company
3. ADDRESS OF OPERATOR
Box 469 Hobbs, N.M. 88240
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: *1980' FSL & 1980' FEL*
AT TOP PROD. INTERVAL: *50 my*
AT TOTAL DEPTH: *50 my*
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

- TEST WATER SHUT-OFF ☐
 FRACTURE TREAT ☐
 SHOOT OR ACIDIZE ☐
 REPAIR WELL ☐
 PULL OR ALTER CASING ☐
 MULTIPLE COMPLETE ☐
 CHANGE ZONES ☐
 ABANDON* ☐
 (other) *core to INT* ☒

(other) Conv. to InJ X

- □ □ □ □ □ □

5. LEASE

5. LEASE
LC-029405(B)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.

10. FIELD OR WILDCAT NAME

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

12. COUNTY OR PARISH | 13. STATE

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

RECEIVED

(NOTE: Report results of multiple completion or zone change on Form 9-330)

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

IT IS Proposed to Expand The North Matamor Grayburg San Andres Waterflood by converting the Mitchell 'B' NOS. 4 + 5 TO Injection Service. This will complete a five spot Pattern around the Mitchell 'B' No. 6.

1. Rig up and Run Bit + Scraper and clean out to 4050'.
2. Set cast Anchor at $\pm 4030'$ with 59x of cast on top. PBTD 2980'.
3. Set RBP at $\pm 3960'$ and PKR at 3870'. Acidize w/1000 Gal Acid w/additives. Flush with 60 Bbls of T.F.W.
4. Re-set RBP at 3870' + PKR at 3650' + Acidize w/1500 Gal of Acidize with additives. Flush w/60 Bbls of T.F.W.
5. Pull Treating Equip and Run 2 3/8" Plastic Lined Tbg. with Tension PKR Set at $\pm 3650'$. Put well on Injection. (JEF/c)

Subsurface Safety Valve: Manu. and Type

Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE ADMN. SUPV. DATE

DATE _____

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

DATE FEB 28 1979

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS (5), F, 10