

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 0294056

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

MCA

8. FARM OR LEASE NAME

MCA Unit

9. WELL NO.

56

10. FIELD AND POOL, OR WILDCAT

Malj. G-SA Reprers.

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

19-17S.-32E

12. COUNTY OR PARISH

Leo

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Injection Well
2. NAME OF OPERATOR Continental Oil Company
3. ADDRESS OF OPERATOR Box 460, Hobbs, N.M. 88240
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1980' FSL & 660' FWC of Sec. 19

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3925' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other) Convert to Water Inj.

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Clean out to TD 3982'. Run tubing w/lines OH BP & set @ 3580' & spot sand on top to 3570-68. Run about 240' of 4 1/2" 9.5# K-55 liner to set from 3565'-3325'. Cement w/50 sks. Class "C" cement. Drill out cmt & test liner to 1000#; squeeze if necessary. Drill out liner shoe & test to 2000#; squeeze if necessary. Drill BP & push to TD. Run cement lined 2 3/8" tubing w/4 1/2" cs9 plcr to set @ ± 3500'. Hook up for injection

WFX Order # 417

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Sr. Analyst

DATE

10-7-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED
OCT 15 1974
ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS-S, MCA-3, File