

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Date approved:
Revised Form No. 40-100

5. LEASE DESIGNATION AND SERIAL NO.
LC-029509(2)

6. IF INDIAN, ALLEGED OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER <u>WATER INJ. WELL</u>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Continental Oil Company	8. FARM OR LEASE NAME BAISH A
3. ADDRESS OF OPERATOR P. O. Box 460, Hobbs, New Mexico 88240	9. WELL NO. 10
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 990' FNL + 980' FEL. SEC. 21	10. FIELD AND FOOT, OR WILDCAT BAISH-VATES
14. PERMIT NO.	11. SEC., T., R., M., OR PLM. AND SURVEY OR AREA SEC. 21, T-17S, R-32E
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 4023' DF	12. COUNTY OR PARISH LEA
	13. STATE N. MEX.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	☐	WATER SHUT-OFF	☐
FRACURE TREAT.	☐	FRACURE TREATMENT	☐
SHOOT OR ACIDIZE	☐	SHOOTING OR ACIDIZING	☐
REPAIR WELL	☐	(Other)	☐
(Other)	☐		
PULL OR ALTER CASING	☐	REPAIRING WELL	☐
MULTIPLE COMPLETION	☒	ALTERING CASING	☐
ABANDON*	☐	ABANDONMENT*	☐
CHANGE PLANS	☐		

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to plug and abandon this well by the following procedures.

Spot a 10 sack cement plug from TD to approx. 2050 (cover perms from 2367' to 2329'). Fill well bore with 10# mud and spot a 10 sack plug at surface. Cap with dry hole marker and clear location.

ABANDONMENT: In addition to above, cut and pull 2-7/8" casing from free point and place 25-sack cement plugs at 300-900 feet and 200-300 feet. If 2-7/8" casing cannot be pulled from below 300 feet, place 100 foot plug inside pipe at 300-900 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED M. E. Yeakley

TITLE Adm. Section

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
AUG 1 0 1970
AS AMENDED
ARTHUR W. BROWN
DISTRICT ENGINEER

DATE 6-25-70

USGS-5 FILE

*See Instructions on Reverse Side