Submit 3 Copies To Appropriate District Office District i Energy	State of New gy. Minerals and	v Mexico Naturai Resources		Form C- Revised March 25.
1625 N. French Dr., Hobbs, NM 87240 District II			WELL API NO. 30-025-20585	
District III 2040 South Pacheco 1000 Rio Brazos Rd., Aziec, NM 87410			5. Indicate Type	
		STATE FEE		
District IV 2040 South Pacheco, Santa Fe, NM 87505	Jama 1 C, 141	41 87303	6. State Oil & C E-8310	as Lease No.
SUNDRY NOTICES AND F (DO NOT USE THIS FORM FOR PROPOSALS TO DRII DIFFERENT RESERVOIR. USE "APPLICATION FOR F PROPOSALS.)	L OR TO DEEPEN O	R PLUG BACK TO A	7. Lease Name or	Umit Agreement Nar
1. Type of Weil: Oil Weil Gas Weil Othe	Water inje	ction well	Mesa Queen I	Init
2. Name of Operator Xeric Oil & Gas Corporation			8. Well No. #16	
3. Address of Operator PO Box 352 Midland, Texas	79702		9. Pool name or W Mesa Queen	
4. Weil Location	19102	-	nesa Queen A	ssociated
Unit Letter J : 2310 fe	ex from theS	outh line and 2	310 feet from	the East lin
		Range 32E		County Lea
1 0. Elevan 4340	·	DR, RKB, RT, GR, etc.)	
11. Check Appropriate		Nature of Notice, R	Report or Other D	
NOTICE OF INTENTION	TO:		SEQUENT REP	ORT OF:
PERFORM REMEDIAL WORK PLUG AND	ABANDON	REMEDIAL WORK		ALTERING CASING
TEMPORARILY ABANDON CHANGE PL	ANS 🖂	COMMENCE DRIL	LING OPNS. 🔲	PLUG AND
PULL OR ALTER CASING	n	CASING TEST AND		ABANDONMENT
COMPLETIO	N	CEMENT JOB		ABANDONMENT
OTHER: Return to active injection	on ⊠	CEMENT JOB OTHER:		(
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE!	(Clearly state all p	OTHER: ertinent details, and giv	re pertinent dates, inc	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE ! or recompilation.	(Clearly state all p	OTHER: ertinent details, and giv	re pertinent dates, inc	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE 1 or recompilation. 1. MIRU PU	(Clearly state all p 103. For Multiple	OTHER: ertinent details, and giv	re pertinent dates, inc	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268'	(Clearly state all p 103. For Multiple	OTHER: ertinent details, and giv Completions: Attach	re pertinent dates, inc	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC	(Clearly state all p 103. For Multiple	OTHER: ertinent details, and giv Completions: Attach	re pertinent dates, inc	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid	Clearly state all p 103. For Multiple /8" tubing tubing set pa	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness preserved.	Clearly state all positions of the control of the c	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all positions of the control of the c	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3, 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3, 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3, 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3, 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations	CEMENT JOB OTHER: ertinent details, and giv Completions: Attach v	re pertinent dates, inc weilbore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p Color of the color of th	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value acker @ 3374' give 24 hr advan	re pertinent dates, incoveribore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations, of starting any proposed work). SEE RULE! or recompilation. 1. MIRU PU 2. Unseat packer and POOH w/2 3, 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness present the start of the start	Clearly state all p Color of the color of th	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value acker @ 3374' give 24 hr advan	re pertinent dates, incoveribore diagram of	luding estimated date
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness presonant per NMOCD regulation. 7. Pressure test per NMOCD regulation. 8. Nipple up well, RDMO PU 9. Return well to water injection.	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations on	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value acker @ 3374' give 24 hr advan	re pertinent dates, incovered bore diagram of ce notice)	luding estimated date proposed completion
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness presonance test per NMOCD regulation. 7. Pressure test per NMOCD regulation. 8. Nipple up well, RDMO PU 9. Return well to water injection. IGNATURE Clember of Glenda Hunt Glenda Hunt	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations on	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value and the completions of the completion of the comp	re perment dates, incoveribore diagram of ce notice)	luding estimated date proposed completion ATE 6/13/01
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3. 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness presonance test per NMOCD regulation. 7. Pressure test per NMOCD regulation. Nipple up well, RDMO PU 9. Return well to water injection.	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations on	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value acker @ 3374' give 24 hr advan	re pertinent dates, incovered bore diagram of ce notice)	luding estimated date proposed completion ATE 6/13/01
OTHER: Return to active injection 12. Describe proposed or completed operations. of starting any proposed work). SEE RULE! or recompliation. 1. MIRU PU 2. Unseat packer and POOH w/2 3 3. RIH and retrieve BP @ 3268' 4. RIH w/packer and 2 3/8" IPC 5. Load backside w/packer fluid 6. Contact NMOCD to witness presonance test per NMOCD regulation. 7. Pressure test per NMOCD regulation. 8. Nipple up well, RDMO PU 9. Return well to water injection. IGNATURE Clember of Glenda Hunt Glenda Hunt	Clearly state all p 103. For Multiple /8" tubing tubing set pa ssure test (g lations on	CEMENT JOB OTHER: ertinent details, and give Completions: Attach value and the completions of the completion of the comp	re pertinent dates, incoveribore diagram of the contice) and belief. n Analyst D 915-683 Telephone	ATE 6/13/0