				Form C-103
NO. OF COPIES RECEIVED		$+f_{-1}$		Supersedes Old
DISTRIBUTION				C-102 and C-103
SANTA FE			ON COMMISSION	Effective 1-1-65
FILE	- <b>-</b>	AUG 🗄   .	to Bir.	5a. Indicate Type of Lease
U.S.G.S.		• 、	14 PH 189	State X Fee
LAND OFF CE	+		5. State Oil & Gas Lease No.	
OPERATOR				
			· · · · · · · · · · · · · · · · · · ·	
DO NOT USE THIS FORM F	JNDRY NOTICES AND R PROPOSALS TO DRILL OR TO D PLICATION FOR PERMIT -" (FOR	REPORTS ON WELLS	DIFFERENT RESERVOIR.	
	PLICATION FOR PERMIT - " (FOR	M C-101) FOR SUCH PROPOS	ALS.)	7. Unit Agreement Name
1. OIL GAS WELL	Dry HC	ole		
2. Name of Operator				8. Farm or Lease Name
Cities Service	011 Company			State CK
3. Address of Operator				9. Well No.
P. 0. Box 69,	Hobbs, New Mexico	88240		#1
4. Location of Well				10. Field and Pool, or Wildcart
G	2040	North	1930	Lovington East
UNIT LETTER	·FEET FROM T	HE LINE	AND / 22	
East	19	165	ANGE 37E	ммрм. (()))))))))))))))))))))))))))))))))))
THE LINE,	SECTION TOW	NNSHIPR	ANGE	
<u>mmmmmm</u>	15. Elevatic	on (Show whether DF, RT,	GR, etc.)	12. County
		3848 DF		Lea ()))))))
<u>(11111):11111111</u>				
	eck Appropriate Box T	lo Indicate Nature		UENT REPORT OF:
NOTICE	OF INTENTION TO:		308324	DENT REPORT OF
				ALTERING CASING
PERFORM REMEDIAL WORK	PLUG A	······	Ē	PLUG AND ABANDONMENT
TEMPORARILY ABANDON		I	NCE DRILLING OPNS.	
PULL OR ALTER CASING	CHANGE	<u> </u>	TEST AND CEMENT JOB	
			ER	
OTHER		L		
17 Describe Proposed or Compl	eted Operations (Clearly state	all pertinent details, and	give pertinent dates, in	cluding estimated date of starting any proposed
work) SEE RULE 1103.	Fred Operations (crossil) state			
TD 11400 Stra	wn - This well was	plugged and aba	endoned in the	following manner;
1. Hole	loaded w/8.9#/ ga	1. drilling mud	•	
2. Disp	laced 25 sx cement	plug through o		1pe 11400-11308.

					F 3						
•	11	-		11	<u>і</u> нТ	11	11	11	11	11	10303-10211.
	11	11	11	11	11	11	11		18	14	9 <b>706-</b> 9614.
	11	11	11	11	11	++		**	18	++	8328-8236.
	44	14	11	11	H	11	11	11	11	18	6354-6262.
	**	11		11	11	18		11	18	11	4411-4319

 $\frac{1}{2}$  in and  $\frac{1}{2}$  out of 8 5/8 casing.

- 3. Cut off casing head and put 10 sx cement plug in top from 30<sup>1</sup> to surface and set 4<sup>1</sup> pipe dry hole marker.
- 4. Location cleaned of all equipment and debris pits filled and location levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	ORIGINAL SIGNED	TITLE District Office Manager.	DATE UIY 31, 1969
APPROVED	BY John w. Remyon	TITLE	DATE