

| | | |
|------------------------|--|--|
| NO. OF COPIES RECEIVED | | |
| DISTRIBUTION | | |
| SANTA FE | | |
| FILE | | |
| U.S.G.S. | | |
| LAND OFFICE | | |
| OPERATOR | | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

7. Unit Agreement Name

8. Form of Lease Name
West Garrett State

9. Well No.
1

10. Field and Pool, or Wildcat
West Garrett

12. County
Lea

SUNDRY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL GAS WELL OTHER- **Saltwater Disposal**

Name of Operator
Osborn Heirs Company

Address of Operator
P. O. Box 179681 San Antonio, Texas 78286

Location of Well
UNIT LETTER **M** **990** FEET FROM THE **South** LINE AND **660** FEET FROM
THE **West** LINE, SECTION **32** TOWNSHIP **16S** RANGE **38E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
3730 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

| | | | |
|--|---|---|--|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| UNEXPECTEDLY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input checked="" type="checkbox"/> |
| DRILL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | OTHER <input type="checkbox"/> |

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set 8 5/8 Cement retainer @ 701'.
2. Pump 400 sks. of Class "C" cement, did not squeeze. Displace cement below retainer.
3. Pressure up on cement. Pump 200 sks. Pull out of retainer. Dump 3/4 BBL. of cement on top of retainer.
4. Circulate 215 sks. of cement in 8 5/8 casing.
5. Dig cellar out. Pump 85 sks. of cement down 13 3/8 casing.
6. Cut wellhead off. Install P & A marker.
7. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Richard J. Betts Baber Well Service
TITLE Rig Supervisor DATE 2-24-87

James R. Smith
TITLE OIL & GAS INSPECTOR DATE 2/24/87

CONDITIONS OF APPROVAL, IF ANY: