

FSI

FR NO: 7274

MC KINLEY AFTERFLOW PLOT

SHUT-IN TIME
 ΔT , MINUTES

1000

100

10

1

T/F = 2500

T/F = 100,000
 $\Delta PF/Q = 2.85 \times 10^{-3}$ @ 119

SHUT-IN PRESSURE

1000

