Form 3160-5 June 1990)	UNIT DEPARTMENT BUREAU OF L.	FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993 5. Lease Designation and Serial No. LC 058697 B 6. If Indian, Allottee or Tribe Name 7. If Unit or CA, Agreement Designation					
Do not use this fo	SUNDRY NOTICES A prm for proposals to dril Jse "APPLICATION FOR						
i. Type or Well X Oil Well Well		N TRIPLICATE	8. Well Name and No.				
2. Name of Operator Conoco, Inc. 3 Address and Telephone & 10 Desta Dr.	Ste 100W, Midland	Pearl B No. 6 9 API Well No. 300252560500 10. Field and Pool. or Exploratory Area Maljamar Grayburg San Andre 11. County or Parish. State Lea, NM					
Location or Well (Footag 660' FSL & 1 Sec. 25, T-							
		TO INDICATE NATURE OF NOTICE, REPO	DRT, OR OTHER DATA				
	PE OF SUBMISSION TYPE OF ACTION						
🖾 Notice o.	i Intent	Abandonment Recompletion Plugging Back	Change of Plans Construction Non-Routine Fracturing				
Final Ab	andonment Notice	Casing Repair Altering Casing Other	Water Shut-Off Conversion to Injection Dispose Water INote: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)				

13. Describe Proposes or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is proposed to plug and abandon this well according to the attached procedure.

4. I hereby contry that the longeoing system and correct Signer DWM MATTOR	Sr. Conservation Coordinator	9/4/91						
(This pace for Foreral or State office use) Approved by Conditions of approval, if any:	Tide 然實設計加速的。在一個的目標是一	Date <u>9 - 19 91</u>						
File 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any raise, fictutious or fraudulent statement or representations as to any matter within its jurisdiction.								

SEP 2 3 1991

## PEARL B NO. 6

## PLUG AND ABANDON

<u>Summary</u>: The following procedure is recommended to permanently plug and abandon Pearl B No. 6:

- 1. Pump through cement retainer @ 4175'. (Drill out and set new retainer if needed).
- 2. Fill 5-1/2" casing and squeeze perforations with 60 sacks of cement.
- 3. Spot 25 sack cement plug on top of cement retainer. Load hole with mud.
- 4. Spot 25 sack cement plug across top of salt and surface casing shoe.
- 5. POOH. WOC. GIH and tag top of plug.
- 6. Pump 25 sacks of cement to set surface plug in 5-1/2" casing.

Location: 660' FSL & 1980' FEL, Unit O, Sec. 25, T-17S, R-32E Lea County, NM

Elevation: 3997' DF (12' AGL)

<u>Completion</u>: Maljamar (G-SA) TD: 4461′ PBTD: 4453′ Perfs: 4381′, 82′, 84′, 86′, 4448′, 50′, 52′ w/2 JSPF

Model K cement retainer @ 4175'.

Casing/Tubing Specifications:

0.D.	Weight	Grade	Depth	Drift	Collapse	Burst	Capacity <u>(bbl/ft) (ft<sup>3</sup>/ft)</u>	
<u>(in) (lbs/ft)</u>			<u>(ft)</u>	<u>(in)</u>	<u>(psi)</u>	(psi)	<u>(bbl/ft)</u>	<u>(ft<sup>3</sup>/ft)</u>
	28.0		1171			2470	.0624	.3505
5-1/2	15.5	K-55	4450	4.825	4040	4810	.0238	.1336
2-7/8	6.5	N-80		2.347	11,160	10,570	.00579	.0325

8-5/8" casing set @ 1171' with 586 sacks cement circulated to surface. 5-1/2" casing set @ 4450' with 1600 sacks cement circulated to surface.

Use safety factor of 70% for collapse and burst pressures. Assume 2-7/8" workstring will be used.

- <u>Notes</u>: 1. All cement slurry used in this procedure shall be Class "C" neat mixed @ 14.8 ppg.
  - 2. All mud shall be 9.5 ppg with 25 lbs gel/bbl brine.
  - 3. Notify BLM prior to commencing any work.

030 1490 28**30**4

JEP 2 2 1833

Pearl B No. 6 Plug and Abandon Page 2

Recommended Procedure:

SAFETY:

- A TAILGATE SAFETY MEETING SHALL BE HELD PRIOR TO COMMENCING ANY WORK.
- **REVIEW VENDOR'S WELLSITE SAFETY PROCEDURES IN ADDITION TO** 2) CONOCO'S APPLICABLE SAFETY PROCEDURES.
- 1. Prepare well for P&A:

1)

- A. MIRU. Bleed pressure down.
- B. ND wellhead and NU BOP.
- C. PU and TIH w/2-7/8" workstring to 4175'.
- 2. Abandon Maljamar (G-SA):
  - Sting into cement retainer @ 4175'. Pump through retainer and Α. establish pump in rate (Drill out and set new retainer at 4175' if needed).
  - Β. MIRU cement services.

## SAFETY: 1) ALL LINES MUST BE PROPERLY STAKED. 2) KEEP A SAFE DISTANCE AWAY FROM ALL PRESSURIZED LINES.

- C. Circulate hole with 100 bbls fresh water. Sting into cement retainer. Establish pump in rate. Maximum surface pressure is 1000 psig.
- Pump 60 sacks cement (30 sacks excess) to fill up 5-1/2" casing and D. squeeze perfs from 4381'-4452'. Sting out of cement retainer. Spot 25 sacks cement on top from 4175'-
- Ε. 3930'. Displace cement with 22 bbls fresh water.
- F. PU to 3930' and load hole with 95 bbls mud.
- G. POOH laying down WS to 1320'.
- 3. Spot cement plug across top of salt and surface casing shoe:
  - A. Load hole with 6 bbls mud.
  - Spot 25 sacks cement from 1320'-1075'. Displace cement with 6 bbls Β. mud.
  - С. POOH with WS. WOC. GIH and tag top of plug.
  - POOH with WS to 245'. D.
- 4. Set surface plug in production casing:
  - Close BOP. Pump 3 bbls mud to load hole and establish circulation up Α. 7" x 2-7/8" annulus.
  - Β. Pump 30 sacks cement (5 sacks excess) to set surface plug in 5-1/2" casing.
  - C. POOH with tubing.
  - D. RD cement services.

с.**ж** Новеј отоб

SEP 23 1991

Pearl B No. 6 Plug and Abandon Page 3

- 5. Prepare surface location for abandonment:
  - A. ND BOP and cut off all casing strings at the base of the cellar or 3' below the final restored ground level (whichever is deeper). RDMO pulling unit.
  - B. Fill the casing strings (if necessary) from the cement plug to surface with cement.
  - C. Cover the wellbore with a metal plate at least 1/4" thick, welded in place, or a cement cap extending radially at least 12" beyond the 8-5/8" casing and at least 4" thick.
  - D. Erect an abandonment marker according to the following specifications:
    - 1. Marker must be at least 4" diameter pipe, 10' long with 4' above restored ground level, and embedded in cement.
    - 2. Marker must be capped and inscribed with the following well information:

Pearl B No. 6 Unit O, Sec. 25, T-17S, R-32E Lea County, NM Date

- Note: 1/4" metal plate can be welded to marker and then to the casing after the marker is set in cement.
- E. Cut off dead-man anchors below ground level and remove markers. Fill in cellar and workover pit.
- F. Remove all equipment, concrete bases, and pipe not in use.
- G. Clean and restore location to its natural state. Reseed according to BLM requirements.
- 6. Send a copy of the well service report and final P&A schematic to the Midland Office so the proper forms can be filed.

## **HCN**IVSD

SEP 2 8 1991 

