

17. Acidize perfs. 7782'-7957' w/12,000 gals 28% NE Acid, 12,000 Gals. Gel Water, 12,000# 100 Mesh Sand & 900# Rock Salt in 3-Equal Stages.
18. Install pumping equipment. Test & place Drinkard on production.