STATE OF NEW MEXICO	
ENERGY AND MINERALS DEPARTMENT	NDIVISION
	Form C-103
SANTA FE SANTA FE, NEW MEX	Kevised 10-
FILE SALES	Sa. Indicate Type of Lease
U.S.G.S.	State X Fee
LAND OFFICE	5. State Oil 6 Gas Lease No.
OPERATOR	V-173
SUNDRY NOTICES AND REPORTS ON WELL	
100 NOT USE THIS FORM FOR PROPOSALS TO UNICE OF FORM C-101) FOR SUCH PROPOS	7, Unit Agreement Name
01L	, One Agrounder Frank
WELL X WELL OTHER-	8. Form or Lease Name
Name of Operator	
Yates Petroleum Corporation	Valentine VL State 9. Well No.
Address of Operator	
105 South 4th St., Artesia, NM 88210	10. Field and Pool, or Wildcat
Location of Well	
UNIT LETTER K 2310 FEET FROM THE South LINE	AND 1650 Saunders Permo Upper P
UNIT LETTER	
THE West LINE, SECTION 10 TOWNSHIP 155	анде <u>33Е</u> нмрм. {{}}}}
15. Elevation (Show whether DF, RT,	, GR, etc.) 12. County
4188.4' GR	Lea
Check Appropriate Box To Indicate Nature	of Notice Report or Other Data
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
NOTICE OF INTENTION TO:	
	ALTERING CASING
	ENCE DRILLING OPNS. PLUG AND ABANDONMENT
EMPORANILY ABANDON	
CHANGE PLANS	A TEST AND CEMENT ION
	E TEST AND CEMENT JOB
	S TEST AND CEMENT JOB
OTHEROTH	d give pertinent dates, including estimated date of starting any prop
OTHEROTH	d give pertinent dates, including estimated date of starting any prop an packer and RBP. potted 2 sacks sand on RBP. Set packer ged cement and squeezed to 1500 psi. ed out. POOH w/packer. RIH w/bit and t plug. Tested squeeze to 500 psi.
<ul> <li>OTHER</li></ul>	d give pertinent dates, including estimated date of starting any prop an packer and RBP. potted 2 sacks sand on RBP. Set packer ged cement and squeezed to 1500 psi. ed out. POOH w/packer. RIH w/bit and t plug. Tested squeeze to 500 psi.
OTHER	A give pertinent dates, including estimated date of starting any prop an packer and RBP. potted 2 sacks sand on RBP. Set packer ged cement and squeezed to 1500 psi. ed out. POOH w/packer. RIH w/bit and t plug. Tested squeeze to 500 psi. 11 returned to production.
orners. OTHER	d give pertinent dates, including estimated date of starting any prop an packer and RBP. potted 2 sacks sand on RBP. Set packer ged cement and squeezed to 1500 psi. ed out. POOH w/packer. RIH w/bit and t plug. Tested squeeze to 500 psi. 11 returned to production.
orners. OTHER	A give pertinent dates, including estimated date of starting any prop an packer and RBP. potted 2 sacks sand on RBP. Set packer ged cement and squeezed to 1500 psi. ed out. POOH w/packer. RIH w/bit and t plug. Tested squeeze to 500 psi. 11 returned to production.