

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-75

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
LG 5986

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- P&A	7. Unit Agreement Name
2. Name of Operator Yates Petroleum Corporation	8. Farm or Lease Name Falcon WI State
3. Address of Operator 105 South 4th, Artesia, NM 88210	9. Well No. 1
4. Location of Well UNIT LETTER L 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 15S RANGE 33E NMPM.	10. Field and Pool, or Whdeat Saunders Permo U. Penn
11. Elevation (Show whether DF, RT, GR, etc.) 4208.4' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1603.

Propose to plug and abandon as follows:

- (1) Set CIBP at 9750' and cap with 35' cement.
- (2) Free point 5 1/2" casing. Cut and pull approximately 50' above free point.
- (3) Spot 100' cement plug in and out of 5 1/2" casing stub. Tag this plug.
- (4) If 5 1/2" stub is below Glorieta formation top at 5699', spot 100' cement plug across this top.
- (5) Spot 100' cement plug 50' in and out of 8 5/8" intermediate casing shoe. Tag this plug.
- (6) Spot 100' cement plug inside 8 5/8" casing across Rustler anhydrite at 1498'.
- (7) Set 15 sack surface plug & abandonment marker.
- (8) Use 10 lb./gal. salt gel between plugs.
- (9) Notify N.M.O.C.D. 24 hours before commencing plugging operations.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Albert L. Stahl TITLE Engineer DATE 12-1-86

Orig. Signed by
Paul Kautz

APPROVED BY Geologist

TITLE

DEC 3 1986