- 6. Install 13-5/8" 5000 psi double hydraulic BOP plus annular & choke manifold. Test casing & BOP to 2000 psi for 30 min.
- 7. Drill 7-7/8" hole to ±9500' with fresh water then convert to salt water to 11,500' then convert to salt water mud weighted as necessary to finish drilling through the Devonian formation to approximately 14,200'.
- 8. Log & evaluate Devonian, Morrow & Atoka formations.



_

~ ~

- -