

NO. OF COPIES RECEIVED	
DISTRICT OFFICE	
SALT LAKE	
FILE	
U.S. GEOLOGICAL SURVEY	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-101
Supersedes C-101
C-102 and C-103
Effective 1-1-65

SUMMARY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR WELLS PRODUCING FROM DIFFERENT RESERVOIRS. USE SEPARATE FORMS FOR EACH DIFFERENT RESERVOIR.		5. Indicate Type of Well State ☐ Free ☒
6. Name of Operator ELK OIL COMPANY		7. Unit Designation Scott
8. Address of Operator Post Office Box 310, Roswell, New Mexico 88201		9. Well No. 3-Y
10. Field and Loc., or Wildcat Undesignated		
11. Elevation (Show whether DF, RT, GR, etc.) 3870. GR		12. County Lea


Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT ON:	
PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER ☐	PLUG AND ABANDON ☒ CHANGE PLANS ☐ OTHER ☐	REMEDIAL WORK ☐ COMMENCE DRILLING OPNGS. ☐ CASING TEST AND CEMENT JOBS ☐ OTHER ☐	ALTERING CASING ☐ PLUG AND ABANDONMENT ☐ OTHER ☐

1. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1403.

Report from November 6, 1984 thru February 15, 1985. Perforated from 10,926'-10,933', 14 holes. Acidize with 1000 gal MOD 202 acid. Swabbed all water. Set Ez Drill @ 10,910, perforate from 10,882'-10,887', 10 holes. Acidize with 1000 gal MOD 202. Swabbed @ rate of 100 bbls water, 5 bbls oil/day. Squeeze perf @ 10,926'-10,933' with 125 sx Class 'H', drilled out to 10,950'. Test to 1200#, all perf's squeezed. Perforate 10,928'-10,940', 20 holes. Acidize with 2500 gals MOD 202. Swabbed all water. Set RBP @ 10,910'; re-perforate 10,842'-10,848', 10 holes. Acidize with 2000 gals MOD 202, swabbed 20 bbls oil, 80 bbls water. Re-acidize with 5000 gals 15% NeFe. Swabbed 8 bbls oil, 44 bbls water. Pull RBP and set @ 10,758', perforate 10,475'-10,480', 12 holes. Acidize with 2500 gals MOD 202, swabbed dry, no show. Prep to Plug and Abandon. Propose to Plug and Abandon as follows:

- 1) Plugs across all perfs.
- 2) Attempt to pull 5½ casing from 8,000', place 50 sx plug in and out of casing stub.
- 3) 100' plug @ Glorietta 6,250'.
- 4) 50 sx @ base of 8 5/8 casing @ 4,725'.
- 5) 100' plug @ Salt 2,600'.
- 6) 10' plug @ surface.
- 7) Standard 4' X 4' dry hole marker.
- 8) Mud between all plugs.

I, Thereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  ORIGINAL SIGNED BY JERRY SEXTON DISTRICT SUPERVISOR	TITLE President	DATE 3/5/85
APPROVED BY	TITLE	DATE MAR - 7 1985

CONDITIONS OF APPROVAL, IF ANY: