

100' (50 sx) cl H' plug from  $\pm 4200' - 4100'$  ( $\pm 50'$  in and out of  $8\frac{5}{8}"$  csg shoe at 4140') Pull up to  $\pm 1450'$  and spot a 100' (35 sx) class H' plug from 1450' - 1350' across the top of salt at 1400'. Pull up to  $\pm 450'$  and spot a 100' (35 sx) class H' cmt plug from  $\pm 450' - 350'$  across the top of  $13\frac{3}{8}"$  csg shoe at 400'. Spot a 10 sx class H' cmt plug at surface, cut off well head, and install PHT marker. Load hole w/ 10# Salt Gel.

RECEIVED

JAN 17 1985

U.S. DEPT.  
HOMER OFFICE