

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-29702
5. Indicate Type of Lease STATE ☒ FEE ☐
6. State Oil & Gas Lease No. LG-7265

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name
LOVINGTON DEEP YATES STATE

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
MOBIL PRODUCING TX & N.M. INC.

8. Well No.
1

3. Address of Operator
12450 GREENSPPOINT DRIVE, HOUSTON, TX 77060-1991

9. Pool name or Wildcat
S. SHOE BAR WOLFCAMP & SOUTH

4. Well Location
Unit Letter P : 330 Feet From The SOUTH Line and 990 Feet From The EAST Line

Section 36 Township 16S Range 35E NMPM LEA County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
GL ELEV: 3934'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	ALTERING CASING ☐
PULL OR ALTER CASING ☐	COMMENCE DRILLING OPNS. ☐
OTHER: ☐	PLUG AND ABANDONMENT ☐
	CASING TEST AND CEMENT JOB ☐
	OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) MIRU, POH W/Rods, ND tree and NU BOP.
- 2) Release TAC & POH w/tbg & TAC.
- 3) GIH w/open ended tbg, spot 25 sx cmt on CIBP @ 9100', pull tbg to 8800', displace the hole w/10 ppg mud, pull tbg to 8600'.
- 4) Spot 25 sx CMT plug @ 8600', pull tbg to 8250', flush tbg, pull tbg to 8000' & WOC.
- 5) GIH w/tbg tag cmt @ (+/-) 8300', pull tbg to 5250', spot 25 sx CMT plug @ 5250', POH.
- 6) GIH w/CIBP, set CIBP @ 3200', spot 25 sx CMT plug @ 3200', pull tbg to 501'.
- 7) Spot 25 sx CMT plug @ 501', POH.
- 8) ND BOP.
- 9) Cut the csg off 4' below surface & GIH w/30' of tbg & circ. CMT to the surface (3 sx).
- 10) Weld cap on casing stub, erect P&A marker, listing well name, company name, P&A date, and location.
- 11) RD & release plugging company.
- 12) Cleanup the location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. APPROVED.
SIGNATURE Patricia B. Swanner TITLE Reg. Tech/Asst. DATE 12/07/94
TYPE OR PRINT NAME Patricia B. Swanner TELEPHONE NO. 775-2081

(This space for State Use)
APPROVED BY TITLE DATE
CONDITIONS OF APPROVAL, IF ANY: