

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

3a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG 3726	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> P&A		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Yates Petroleum Corporation		Sandsage State Unit
3. Address of Operator		9. Well No.
105 South 4th St., Artesia, NM 88210		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>E</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM		Wildcat
THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>15S</u> RANGE <u>35E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4019' GR		Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

OTHER ☐

PLUG AND ABANDON ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOBS ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug and abandon well as follows:

Set CIBP at 11275' and cap w/35' cement.

Load hole w/10#/gal salt gel mud.

Freepoint 5-1/2" casing and pull (top of cement is 9970' by cement bond log).

Spot cement plug thru tubing 50' in and out of casing stub. Tag plug.

Spot cement plug from 8190-8090' across Abo top.

Spot cement plug from 5382-5282' across Glorieta top.

Spot cement plug 50' in and out 8-5/8" casing shoe from 4767-4667'. Tag plug.

Spot cement plug inside 8-5/8" casing from 1925-1825' across top of salt.

Set 10 sx plug at surface.

Install regulation abandonment marker.

Verbal approval for above plugging given by Mr. Eddie Seay, NMOCD, Hobbs on 10-30-86.

Note: All plugs must be 100' or 25 sacks cement, whichever is greater.

NOTIFY NMOCD, HOBBS, 24 HOURS BEFORE STARTING PLUGGING OPERATIONS.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Production Supervisor DATE 10-31-86

ORIGINAL SIGNED BY JERRY TAYLOR

APPROVED BY DISTRICT 1 SUPERVISOR TITLE DATE NOV 3 1986

CONDITIONS OF APPROVAL, IF ANY: