

Shipp "34" No. 4
Recomplete to the Lovington
(San Andres)
Page 2

8. Place well on production. Obtain rods, pump, pumping unit, etc. from Shipp 34-2.
 - A. POH with tubing and packer.
 - B. GIH with MA, PN, SN, and TA on 2-7/8" tubing. Put SN at 5250' +/- and TA at 5060' +/- . Will have to buy TA.
 - C. ND BOP, set TA, and NU wellhead.
 - D. Run 1-1/4" pump, 146 3/4" rods, and 64 7/8" rods.
 - E. Clamp well off.
 - F. Move pumping unit from Shipp 34-2 to Shipp 34-4.
 - G. Hook up electricity, HWO, and put well on production.

JLG:sw