ubmit 3 Copies 5 Apropriate District Office	State of New M Energy,oerals and Natural I		Form C-103 Revised 1-1-89
DISTRICT I	OIL CONSERVATI	ON DIVISION	
Box 1980, Hobbs, NM 88240	P.O. Box 20		WELL API NO. 80-025-29998
DISTRICT II O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mexico	87504-2088	5. Indicate Type of Lease STATE FEE X
<u>DISTRICT III</u> 000 Rio Brazos Rd., Aztec, NM 87410)		6. State Oil & Gas Lease No.
	TICES AND REPORTS ON WE		
(DO NOT USE THIS FORM FOR F DIFFERENT RES (FORM	PROPOSALS TO DRILL OR TO DEEPE SERVOIR. USE "APPLICATION FOR P I C-101) FOR SUCH PROPOSALS.)	N OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name
Type of Well: OIL GAS WELL WELL [X OTHER		Arreguy AVM
Name of Operator YATES PETROLEUM CORP	<u>, , , , , , , , , , , , , , , , , , , </u>		8. Well No.
Address of Operator			9. Pool name or Wildcat
105 South 4th St., A	rtesia, NM 88210		Wildcat Mississippian
. Well Location		<u></u>	
Unit Letter :8	10 Feet From The North	Line and510) Feet From The East Line
Section 25	Township 15S	Range 34E	NMPM Lea County
Section 25	10. Elevation (Show wheth		
	403	5.5' GR	
1. Chec	k Appropriate Box to Indicate	Nature of Notice, F	Report, or Other Data
NOTICE OF I		1 011	BSEQUENT REPORT OF:
	NIENTION IU:	SUL	
	1 [
		SUL REMEDIAL WORK	
	1 [
		REMEDIAL WORK	G OPNS.
ERFORM REMEDIAL WORK		REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C	ALTERING CASING G OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER:	ALTERING CASING OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry
ERFORM REMEDIAL WORK	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry wding estimated date of starting any proposed
ERFORM REMEDIAL WORK	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry wding estimated date of starting any proposed
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2. Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead.	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS Certations (Clearly state all periment details, dry hole marker. Insta	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry Wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11"
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2. Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel ools. Nippled u	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP.
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2. Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347'	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel ools. Nippled u sted BOP to 3000	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry Z uding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all pertiment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry 2 wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl lled 6' X 6' cel ools. Nippled us sted BOP to 3000 Spudded in at gged cement at f rillpipe. Circu	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug ilated hole clean. Picked up
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up ment from 4310-4347'.
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347'	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at f rillpipe. Circu 0'. Drilled cer agged up on cas	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up ment from 4310-4347'. ing stub at 4344'. TOOH.
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2. Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at 1 rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11a
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all pertinent details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cast up power swivel circulated. Lat rer swivel. Dri	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" Ap BOP. D# and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11a
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all pertinent details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow and pumped sweep. Rig	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas up power swivel circulated. Lat rer swivel. Drii	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" Ap BOP. D# and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11a
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347'	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up power and pumped sweep. Rig . Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give pertinent dates, incl 11ed 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at a rillpipe. Circu 0'. Drilled cer agged up on cas up power swivel circulated. Lat rer swivel. Dri ged down power s s and lay down r	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347'	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up power and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11at
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347'	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Creations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t . Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 . Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up power and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed O work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347' I hereby certify that the information above in	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wing estimated date of starting any proposed lar. Welded on 8-5/8" X 11" up BOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11at
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed Of work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly and drill collars and dd from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347' I hereby certify that the information above in Stonature	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole starting and TOOH. Dressed off 5-1/2" casing 11d down swivel and TOOH. RIH 11ed cement inside of 5-1/2" swivel. 11achine. Ran 105 joints of 11NUED ON NEXT PAGE: Technician DATE Dec. 8, 2000
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed O work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347' I hereby certify that the information above in stonature TYPE OR PRINT NAME	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole starting and TOOH. Dressed off 5-1/2" casing 11d down swivel and TOOH. RIH 11ed cement inside of 5-1/2" 15wivel. 11achine. Ran 105 joints of 11NUED ON NEXT PAGE: 11echnician DATE Dec. 8, 2000 TELEPHONE NO. 505/748-1
ERFORM REMEDIAL WORK EMPORARILY ABANDON JLL OR ALTER CASING THER: 2 Describe Proposed or Completed O work) SEE RULE 1103. 8-4-2000 - Dug out 3000K wellhead. 8-5-2000 - Moved in 8-6-2000 - TD 4347' up bit and kelly an drill collars and d from 1885-1980'. P drillpipe and TIH a 8-7-2000 - TD 4347' Picked up dress off (milled 3' off casi with bit and drill casing. Circulated 8-8-2000 TD 4347' I hereby certify that the information above in stonature TYPE OR PRINT NAME	PLUG AND ABANDON CHANGE PLANS CHANGE PLANS CHANGE PLANS Cerations (Clearly state all periment details, dry hole marker. Insta and rigged up rotary t Drilling cement. Te d drilled surface plug. rillpipe and TIH and ta icked up 30 joints of d nd tagged cement at 431 Drilled cement and t mill and TIH. Rigged ng). Pumped sweep and collars. Rigged up pow and pumped sweep. Rig Rigged up power tong	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud or and give periment dates, incl lled 6' X 6' cel ools. Nippled u sted BOP to 3000 Spudded in at gged cement at rillpipe. Circu 0'. Drilled cer agged up on cas: up power swivel circulated. Lat rer swivel. Dri gged down power s and lay down m	ALTERING CASING G OPNS. PLUG AND ABANDONMENT EMENT JOB a re-entry wding estimated date of starting any proposed lar. Welded on 8-5/8" X 11" PBOP. # and hydril to 1500#. Picked 5:15 PM 8-5-2000. Picked up 1885'. Drilled cement plug 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole clean. Picked up 11ated hole starting and TOOH. Dressed off 5-1/2" casing 11d down swivel and TOOH. RIH 11ed cement inside of 5-1/2" swivel. 11achine. Ran 105 joints of 11NUED ON NEXT PAGE: Technician DATE Dec. 8, 2000

٥