

02/07/95 Cut off wellhead, clean pits and set surface cement plug @ 35' and
install dry hole marker. Witnessed by Gary Wink.