

DISTRICT I
P. O. Box 1980, Hobbs, NM 88240

DISTRICT II
P. O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P. O. Box 2088
Santa Fe, NM 7504-2088

| |
|---|
| WELL API NO. 30-025-01508 |
| 5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/> |
| 6. State Oil & Gas Lease No. B-2148 |
| 7. Lease Name or Unit Agreement Name Caprock Maljamar Unit |
| 8. Well No. 72 |
| 9. Pool name or Wildcat Maljamar Grayburg San Andres |

| | |
|---|--|
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) | |
| 1. Type of Well: OIL <input type="checkbox"/> GAS <input type="checkbox"/> WELL <input type="checkbox"/> WELL <input type="checkbox"/> OTHER <input type="checkbox"/> P & A | |
| 2. Name of Operator The Wiser Oil Company | |
| 3. Address of Operator P.O. Box 2568 Hobbs, New Mexico (505) 392-9797 | |
| 4. Well Location Unit Letter L : 1980 Feet From The South Line and 660 Feet From The West Line Section 21 Township 17S Range 33E NMPM Lea County | |
| 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4176' | |

| | |
|---|---|
| 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data | |
| NOTICE OF INTENTION TO | SUBSEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> |
| OTHER: <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
| | OTHER: <input type="checkbox"/> |

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Wiser requests approval to plug and abandon the well by the procedure listed below.

1. POH w/production equipment. TIH w/CIBP & set @ 4200'.
2. Dump 25 sks. cement on CIBP. Tag cement plug.
3. Circulate abandonment mud.
4. Set 25 sks. cement plug @ 1400'. **SET 25 SK @ 2600' to 2500' BASE OF SALT**
5. Tag plug @ 1400'.
6. Perforate csg. @ **350'** & circulate cement to surface.
7. Set 10 sks. cement @ 50' from surface.
8. Install dry hole marker.
9. Clean location. RDMO.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE **M. Jones** TITLE **Superintendent** DATE **September 28, 2000**
TYPE OR PRINT NAME **Mike Jones** TELEPHONE NO. **(505) 392-9797**

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____