

JAN 8 1983

6. RIH w/4-3/4" RH 6-3-1/2" DCs & 5-1/2" csg scraper on 2-3/8" tbq & DO cmt & retainer. CHC. Press tst sqz & csg to 1000#. Drill out CIBP @ approx. 4250'. CHC. POOH.
7. RIH w/5-1/2" nickel plated inj pkr on 2-3/8" cmt lined tbq. Circ hole w/inhibited pkr fluid. Set pkr @ approx. 4225'. Press tst tbq in hole. ND BOP. NU WH. HU inj line & put well on injection.

