

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ <u>shut-in</u>	7. UNIT AGREEMENT NAME <u>MCA</u>
2. NAME OF OPERATOR <u>CONOCO INC.</u>	8. FARM OR LEASE NAME <u>MCA Unit Bty 4</u>
3. ADDRESS OF OPERATOR <u>P. O. Box 460, Hobbs, N.M. 88240</u>	9. WELL NO. <u>199</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) <u>Unit K</u>	10. FIELD AND POOL, OR WILDCAT <u>Mahamar 6/5A</u>
14. PERMIT NO. <u>30-025-01563</u>	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>33</u> <u>Sec. 30-175-32E</u>
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH <u>Lea</u>
	13. STATE <u>NM</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETION ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) <u>Run liner & Ret to prod.</u> ☒	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	
(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- ① MVRU. POOH w/ tbg & pkr. Swage out collapsed csg from 2053'-2068'.
- ② POOH w/ RBP @ 3910'. Set CIBP @ ±3940', but not lower than 3945'.
- ③ Run 3940' of 4½", K-55, ST & C in hole. Set float collar @ 1900' & D.V. tool @ 1990'. Cement from 3940' to surface as follows:
 - a) lead-in w/ 215 SXS class "C" cmt, drop plug & flush w/ 62 bbls FW.
 - b) Drop D.V. bomb to open D.V. tool
 - c) lead-in w/ 230 SXS class "C" cmt. Drop plug & flush w/ 33 bbls FW.
- ④ Drill out cmt & CIBP @ 3940'. Clean out top of junk @ 4248'.
- ⑤ Set treating pkr @ 3910'. Acidize Grayburg, San Andres open hole perms w/ 50 bbls HCL-NE-FE w/ 400/lbs rock salt mixed 5 bbls 10 ppg brine pumped in between. Overflush w/ 30 bbls KCL TFW. Swab back load.
- ⑥ GIH w/ prod. equip., place on test & rig down.

18. I hereby certify that the foregoing is true and correct

SIGNED DE FINNEY

TITLE Administrative Supervisor

DATE 12-4-86

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 12-4-86

*See Instructions on Reverse Side