

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
B-1356

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Koch Exploration Company	8. Farm or Lease Name Miller State
3. Address of Operator P.O. Box 2256, Wichita, KS 67201	9. Well No. 2
4. Location of Well UNIT LETTER O 660 FEET FROM THE S LINE AND 1980 FEET FROM THE E LINE, SECTION 4 TOWNSHIP 17S RANGE 34E NMPM.	10. Field and Pool, or Wildcat Vacuum/Grayburg SA
15. Elevation (Show whether DF, RT, GR, etc.) 4080 Gr.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Ran 5-1/2" CIBP & 2-3/8" tbgr. Set CIBP @ 4500'
2. Spot 5 sx cmt on top of CIBP
3. Circ. hole to surface w/mud
4. Tag cmt plug @ 4453'
5. Pull tbgr up to 2740', spot 15 sx cmt plug.
6. Tag top of cmt plug @ 2603'
7. Chemical cut 5-1/2" csg off @ 2315', pull & lay down same.
8. Ran tbgr to 2520', spot 65 sx cmt plug.
9. Tag top of cmt plug @ 2220'. Pull tbgr up to 1575'. Spot 50 sx cmt plug.
10. Tag top of cmt plug @ 1445' (75') up inside of 8-5/8" surf csg.
11. Set 10 sx cmt plug in top of 8-5/8" surf csg w/regulation dry hole marker

Well P & A 1/30/85

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Vernon J. Lowe</u>	TITLE <u>Operations Manager</u>	DATE <u>3/1/85</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>OCT 25 1985</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAR -6 1985

HOUSE OFFICE