

WELL WORK RECOMMENDATIONS
Proposals for Well Reconditioning and Subsurface Maintenance
Workovers, Expense DD's, PB's, and Conversions

Lease: BRIDGES STATE Well No. 87

Field: VACUUM - SAN ANDRES FLOOD

County: LEA State: NEW MEXICO

RECOMMENDED PROCEDURE:

1. M.I.P.U. & PULL DOWN HOLE EQUIPMENT & TUBING
2. RUN 2" TUBING w/ CEMENT RETAINER. SET RETAINER
AT 4640' & SQUEEZE OPEN HOLE
3. CIRCULATE HOLE TO MUD LADEN FLUID
4. SPOT 20SX CEMENT PLUG FROM 1610' TO 1710'
5. SPOT 10SX CEMENT PLUG AT SURFACE
6. CUT OFF WELL HEAD & INSTALL MARKER