NO. OF CO S RECEIVED DISTRIBUTION			Form C-103 Supersedes Old
SANTA FE FILE	NEW MEXICO OIL CON	NEW MEXICO DIL CONSERVATION COMMISSION	
U.S.G.S. LAND OFFICE			Sa. Indicate Type of Lease State X Fee
OPERATOR			5. State Cil & Gas Lease No.
(DO NOT USE THIS FORM F	UNDRY NOTICES AND REPORTS ON PHOPOSALS TO DRILL OR TO DEEPEN OR FUNG PLUGATION FOR PERMIT HIS FORM CHICKLES	WELLS	\$ - 1.5 2 0
OIL S GAS	PLICATION FOR PERMIT 14 (FORM C-101) FCR EU	CH PROPOSALS.	7. Unit Agreement Name
2. Name of Operation	8, Farm or Lease Name		
Molis del Corporation 3. Address of Exercitor Back 6 3 3, Midland, Julas 79701 4. Location of Well			9. Well No.
4. Location of Well	10. Field and Pool, or Wildcat		
UNIT LETTER . 1920 FEET FROM THE Duith LINE AND 1980 FEET FROM			Vae (&- 2A)
THE Wast LINE,	SECTION 12 TOWNSHIF 171	RANGE 34E NMPM	
	15. Elevation (Show whether	DF, RT, GR, etc.) - (2 K.	12. Sounty
Ch	ther Data		
PERFORM REMEDIAL WORK	PLUG AND ABANDON	SUBSEQUENT	
TEMPORARILY ABANDON PULL OR ALTER CASING	CHANGE PLANS	COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JOB	ALTERING CASING PLUG AND ABANDONMENT
OTHER		OTHER	· .
17. Describe Proposed or Complete work) SEF Rui F 1703	ted Operations (Clearly state all pertinent det	ails, and give pertinent dates, including	g estimated date of starting any proposed
Plug + al	andon ar per atta	eled recommends	teor
17 .	ation above is true and complete to the best	my knowledge and belief.	
IGNED Christine O.		extern Clark	DATE 1-11-73-
PPROVED BY	Orig. Signed by Joe D. Ramey		JAN 15 1973
ONDITIONS OF APPROVAL, IF	- Li. (DATE

MIDLAND E & P DIVISION

WELL WORK RECOMMENDATIONS Proposals for Well Reconditioning and Subsurface Maintenance Workovers, Expense DD's, PB's, and Conversions

Lease:	Bridges State	Well No. 88	88	
Field:	Vacuum-San Andres Flood			•
County:	Lea	State:	New Mexico	

RECOMMENDED PROCEDURE:

- 1. M.I.P.U. & pull downhole equipment.
- 2. Run 2" tbg w/ cement retainer. Set retainer at 4610' and squeeze open hole.
- 3. Circulate hole to mud laden fluid.
- 4. Determine free point of 5-1/2" casing. Cut and pull.
- 5. Spot 25 sx cement plug 50' above and 50' below cut.
- 6. Spot 30 sx cement plug from 1660' to 1760' if cut is below same. Spot 20 sx cement plug from 1660' to 1760' if cut is above 1500'.
- 7. Spot 10 sx cement plug at surface.
- 8. Cut off well head and install marker.

DIAG IMMATIC WELL SKETCHT

BRIDGES STATE WELL Nº 88

VACUUM- SAN ANDRES FLOOD

LEA COUNTY- NEW MEXICO

