

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1306	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		San Andres Unit
3. Address of Operator		8. Farm or Lease Name
P. O. Box 70, Santa Fe, New Mexico 87501		San Andres Unit
4. Location of Well		9. Well No.
UNIT LETTER J 1980 FEET FROM THE LINE AND 1980 FEET FROM THE		27
10. Field and Pool, or Wildcat		
The 10th LINE, SECTION 1 TOWNSHIP 10-S RANGE 34-E NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3450' (GR)		Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Pull rods & pump. Install 10". Pull Tubing.
2. Clear out.
3. Drill from open hole 4050' - 4600' w/ 1000 gals. 15% NEEF Acid in 2 stages using 750" rock salt & 3000" anhyd acid between stages.
4. Treat w/ 3000" rock salt & 700" anhyd acid followed w/ 2000 gals. 15% NEEF Acid
5. Install Pumping equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 2-17-83

APPROVED BY SIGNED BY JERRY SEXTON TITLE DISTRICT 1 SUPERVISOR DATE FEB 21 1983

CONDITIONS OF APPROVAL, IF ANY: