

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-3936
7. Unit Agreement Name West Vacuum Unit
8. Farm or Lease Name West Vacuum Unit
9. Well No. 44
10. Field and Pool, or Wildcat Vacuum Grayburg San Andres
12. County Lea

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>
2. Name of Operator TEXACO Inc.
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240
4. Location of well UNIT LETTER <u>C</u> , <u>669</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>3</u> TOWNSHIP <u>18-S</u> RANGE <u>34-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4041' (DF)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Pull tubing & pkr.
2. Set RBP @ 3600' & dump 20; San d on plug.
3. Perforate 5 1/2" Csg w/2-JSPF @ 1670'.
4. Set cement retainer @ 1591'. Cement perms @ 1670' w/600 Sx. Class 'H' Cement containing 2% CaCl. Cement circulated. Squeeze w/200 Sx. Class 'H' Cement. WOC. DOC. Tested OK.
5. Install Water Injection equipment. Return to Injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. L. Chaffin</u>	TITLE <u>Asst. Dist. Mgr.</u>	DATE <u>6-4-81</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		