

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-3936	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>		7. Unit Agreement Name <b>West Vacuum Unit</b>
2. Name of Operator <b>TEXACO Inc.</b>		8. Farm or Lease Name <b>West Vacuum Unit</b>
3. Address of Operator <b>P. O. Box 728, Hobbs, New Mexico 88240</b>		9. Well No. <b>44</b>
4. Location of Well UNIT LETTER <b>C</b> <b>669</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>3</b> TOWNSHIP <b>18-S</b> RANGE <b>34-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Vacuum, Grayburg San Andres</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4041' (DF)</b>		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Repair Water Flow</b>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull tubing & packer.
2. Set RBP @ 4000' & spot 20' Sand on plug.
3. Perforate 5 1/2" Csg w/2-JS @ 1670'.
4. Set cement retainer @ 1570'. Cement to surface Csg perfs. @ 1670' w/300 sx. Class 'H' Cement. Squeeze w/addl. 200 sx. Class 'H' Cement. WOC. DOC. Test.
5. Install injection equipment. Return to injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE **Asst. Dist. Mgr.** DATE **2-24-81**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: