

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

B-3936

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	Vest Vacuum Unit
3. Address of Operator	8. Farm or Lease Name
P. O. Box 728, Hobbs, New Mexico 88240	Vest Vacuum Unit
4. Location of Well	9. Well No.
UNIT LETTER <u>XC</u> = <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>1780</u> FEET FROM THE <u>East West</u> LINE, SECTION <u>24</u> TOWNSHIP <u>12-S</u> RANGE <u>24-E</u> NMPM.	10. Field and Pool, or Wildcat
	Vacuum Grayburg
	San Andres
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4022' (DF)	Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull production equipment. Install BOP.
2. Set RSP @ 4100'.
3. Perforate 5 1/2" csg w/2-JS @ 1675'.
4. Set cement retainer @ 1450'. Cement perfs. @ 1675' w/250 sx. class "H" cement. Circulate cement. Squeeze w/addl 150 sx. cement. WOC. DOC. Test. Pull RBP.
5. Install production equipment. Test & return to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Assistant District Manager DATE 7/16/81
APPROVED BY [Signature] TITLE [Signature] DATE JUL 20 1981
CONDITIONS OF APPROVAL, IF ANY: