

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION C.

JAN 13 11 21 AM '67

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-8539</b>	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator <b>Sunray DX Oil Company</b>		8. Farm or Lease Name <b>New Mexico "G" State</b>	
3. Address of Operator <b>P. O. Box 1416, Roswell, New Mexico</b>		9. Well No. <b>1</b>	
4. Location of Well UNIT LETTER <b>M</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>18S</b> RANGE <b>34E</b> NMPM.		10. Field and Pool, or Wildcat <b>E. K. Queen</b>	
15. Elevation (Show whether DF, RT, GR, etc.) <b>4092 (DF)</b>		12. County <b>Lea</b>	

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Placed 25 sx. cmt. plug over perfs at 4335'.
2. Cut off 5 1/2" csg at 1119' and pulled csg.
3. Placed 25 sx. cmt. plug in and out of 5 1/2" stub at 1119'.
4. Placed 25 sx cmt. plug at 1120' in base of salt.
5. Laid 25 sx. cmt. plug in base of surface casing at 268'.
6. Placed 10 sx. cmt. plug at surface.
7. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED B.F. Brawley TITLE District Engineer DATE January 12, 1967

APPROVED BY John W. Runyan TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: