

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. Unknown

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name -
2. Name of Operator Sunray DX Oil Company	8. Farm or Lease Name New Mexico "H" State
3. Address of Operator P. O. Box 1416, Roswell, New Mexico	9. Well No. 1
4. Location of Well UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 7 TOWNSHIP 18S RANGE 34E NMPM.	10. Field and Pool, or Wildcat E. K. Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4081 G.L.	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Loaded hole with mud laden fluid.
- Spotted 25 sx cmt. plug from 4404-4300.
- Layed down tubing.
- Shot off csg at 997'. Pulled casing.
- Spot 25 sx cement plug from 3230-3100'.
- Spot 25 sx cement plug from 1015-915'.
- Spot 25 sx cement plug from 250-150'.
- Lay 10 sx cement plug in top of surface pipe.
- Placed identification marker in top of well.
- Filled pits, leveled location and removed excess material.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Hastings John Hastings TITLE District Engineer DATE May 8, 1967

APPROVED BY Leslie A. Clements TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: