

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)		5a. Indicate Type of Lease State ☒ Fee ☐ 5. State Oil & Gas Lease No. B-2131
1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ 2. Name of Operator Phillips Petroleum Company 3. Address of Operator Room 711, Phillips Building, Odessa, Texas 79761 4. Location of Well UNIT LETTER C 330 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 4 TOWNSHIP 18S RANGE 35E N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.) DF-4600'	7. Unit Agreement Name 8. Farm or Lease Name Santa Fe 9. Well No. 46 10. Field and Pool, or Willcat Vacuum Gb/SA 12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER ☐		SUBSEQUENT REPORT OF: PLUG AND ABANDON ☒ CHANGE PLANS ☐ OTHER ☐ REMEDIAL WORK ☐ COMMENCE DRILLING OPNS. ☐ CASING TEST AND CEMENT JOB ☐ OTHER ☐ ALTERING CASING ☐ PLUG AND ABANDONMENT ☐	
--	--	--	--

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well Shut-in in 5-5-67.

Propose to P & A as follows: Shoot fluid level.

1. Pull rod to part on back off fish.
2. Run outside shot and back off fish.
3. Spot 30 sx of class "H" cement w/1/4#/sx Flocale mixed to 15.6#/gal from 50' below top of fish to 50' above top of fish.
4. Displace w/mud laden fluid and pull tbg.
5. Cut and pull 5 1/2" casing at free pt. based on stretch (estimated TOC @ 2523').
6. Run tbg and spot cement plugs--
 - a) If 5 1/2" csg cut below 1940', then spot 30 sx of class "H" cement from 50' below to cut to 50' above the cut. Then spot 62 sx of class "H" cement from 1940' to 1510' to cover the top of the Salt and Rustler.
 - b) If 5 1/2" csg is cut above 1940' and below 1560', then spot 62 sx of class "H" cement from 50' below the cut to 50' above top of Rustler, (top of Rustler 1560').
 - c) If 5 1/2" csg is cut above 1560', then spot 30 sx of class "H" cement from 50' below the cut. to 50' above the cut.

Continued on Reverse Side

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

W. J. Mueller TITLE Senior Reservoir Engineer DATE 11-7-74

APPROVED BY TITLE DATE

CONDITIONS OF APPROVAL, IF ANY:

7. Pull tbq.
8. Cut well head and spot 10 sx class "H" cement for surface plug.
9. Install well marker and clean location.